



# HP TouchSmart 15-r015dx Battery Replacement

This guide will show you how to replace the battery of your HP TouchSmart 15-r015dx.

Written By: Jacob Kleinsorge



## INTRODUCTION


The HP TouchSmart 15-r015dx has a 3-cell lithium-ion polymer battery that fits nicely on the bottom of the laptop.

## Step 1 — Battery



- Turn off your laptop.
- ⚠ Ensure your laptop is off. Removing the battery while it is on may harm your laptop.
- Flip upside down in order to access the battery.

## Step 2



- There are two battery release switches located under the battery.
- Slide both switches inward to release the battery.

## Step 3



- Remove the battery.
- ⓘ The release switches may need to be pushed inward while removing the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 12:19:11 AM.